












# User Manual

1. Make sure power is off before installation;
2. Copper line must be fully covered, then carry the power line to make sure it's fixed.
3. This manual is suitable for XTD-B series product.


## 1. Make the cut hole and install the trim.



XTD-B Series cut hole table.


Item Number	Cut Hole
 XTD-B-01	 42*41MM
 XTD-B-02	 72*41MM
 XTD-B-05	 145*41MM
 XTD-B-10	 277*41MM
 XTD-B-15	 410*41MM

## 2. Paint the ceiling and the trim.




Make sure the power is off before wiring!

## 3. Installation.



Pull up the spring and put the light into the preinstalled trim.



Installation complete.